
Genie H 8000 07 Guide

*Downloaded from
www.whlarchitecture.com
by Chambers & Reilly*

INTRODUCTION TO THE GENIE H 8000 07 GUIDE

When it comes to reliable and durable garage door openers, the Genie H 8000 07 stands out as a trusted workhorse in the residential market. Whether you are a new homeowner looking to install your first automatic garage door operator or a seasoned DIY enthusiast seeking to replace an aging unit, this **Genie H 8000 07 guide** will walk you through

everything you need to know. From unboxing and installation to programming, maintenance, and troubleshooting, this article covers all the essential information to help you get the most out of your Genie H8000-07 garage door opener.

The Genie H 8000 07 is part of Genie's renowned line of chain drive openers, known for their robust construction, reliable performance, and long service life. In this guide, we will explore the key features, step-by-step installation procedures, programming instructions

for remotes and keypads, common issues and their solutions, and best practices for keeping your opener running smoothly for years to come. By the end of this article, you will have a thorough understanding of how to operate, maintain, and troubleshoot your Genie H8000-07 garage door opener confidently.

KEY FEATURES AND SPECIFICATIONS OF THE GENIE H 8000 07

Before diving into installation and usage, it is helpful to understand what makes the Genie H8000-07 a popular choice among homeowners. This model is designed with a combination of power, durability, and user-friendly technology that simplifies everyday operation.

Powerful Chain Drive Mechanism

The Genie H 8000 07 utilizes a robust chain drive system that delivers consistent lifting power for heavy sectional garage doors. Chain drive openers are known for their strength and longevity, making this model an excellent choice for double-car garage doors or doors constructed from heavier materials such as wood or steel. The motor is rated at 1/2 horsepower, which is sufficient for most residential applications.

Integrated Lighting System

One of the standout features of the Genie H 8000 07 is its integrated lighting system. The unit comes equipped with two bright 100-watt bulbs that illuminate the garage interior automatically when the opener is activated. This provides valuable visibility when entering or exiting the garage at night and enhances overall safety. The lights can also be set to remain on for a programmable duration after the door closes.

Safe-T-Beam Sensor System

Safety is a top priority with any garage door opener, and the Genie H 8000 07 includes the Genie Safe-T-Beam system. This infrared sensor is installed near the floor on both sides of the garage door opening. If an object, pet, or person breaks the beam while the door is closing, the system automatically reverses the door direction, preventing accidents and injuries. This feature is required by federal safety standards and provides peace of mind for families with children and pets.

Intellicode Access Security

The Genie H 8000 07 uses Genie's patented Intellicode technology, which automatically changes the access code each time the remote is used. This rolling code system prevents unauthorized individuals from capturing and replaying your remote signal, significantly enhancing the security of your home. Each remote and keypad is synced to the opener using a unique code that cannot be duplicated.

Manual Emergency Release

In the event of a power outage, the Genie H 8000 07 features a manual emergency release handle. Pulling this cord disengages the opener from the door, allowing you to operate the garage door manually. This is an essential feature that ensures you are never locked out of your garage when electricity is unavailable.

STEP-BY-STEP INSTALLATION

GUIDE FOR THE GENIE H 8000 07

Materials

Proper installation is critical for the safe and efficient operation of your garage door opener. The following steps provide a general overview of the installation process. Always refer to the manufacturer's manual for your specific model, as details may vary slightly based on your garage door configuration.

Prepare Your Tools and

Before starting, gather the necessary tools: a power drill with assorted bits, screwdrivers (Phillips and flathead), a level, a tape measure, a ladder, a socket wrench set, and a pencil. Ensure that you have the mounting hardware included with your Genie H 8000 07 kit, including the rail sections, chain, brackets, and bolts.

Assemble the Rail and Trolley

Begin by assembling the rail sections on a flat surface. Follow the instructions to connect the rail pieces securely, then

thread the chain through the rail system. Attach the trolley (the carriage that moves along the rail) according to the diagram. Ensure the chain is properly tensioned but not overly tight. Most Genie models include an adjustment mechanism for fine-tuning chain tension.

Mount the Opener to the Ceiling

Use the included ceiling brackets to attach the power head (the main motor unit) to the garage ceiling. Position the opener so that the rail is centered over the garage door. The power head should

be mounted high enough to provide clearance for the door when it is fully open. Use a level to ensure the rail is perfectly horizontal. Secure all bolts and brackets tightly.

Attach the Rail to the Door Bracket

Install the door bracket to the top section of your garage door, following the manufacturer's guidelines. Connect the rail to the door bracket using the provided pins and fasteners. The trolley should be in the closed-door position when attaching. Double-check that the rail is aligned properly with the door track to prevent binding during operation.

Install the Safe-T-Beam Sensors

Mount the infrared sensors on both sides of the garage door opening, no more than six inches above the floor. Ensure the sensors face each other and are aligned so that the indicator lights show a steady glow. Connect the sensor wires to the terminals on the power head. This step is essential for safety compliance and must not be skipped.

Wire the Wall

Console

Install the wall console in a convenient location inside the garage, typically near the service door or entry to the house. Run the low-voltage wiring from the console to the power head and connect it to the designated terminals. The wall console provides push-button operation and may include a lock feature and light control.

Connect Power and Test

Plug the power head into a grounded electrical outlet. Before finalizing the installation, perform a series of tests:

open and close the door using the wall console, verify that the safety sensors reverse the door when obstructed, and check that the auto-reverse function operates correctly. Adjust the travel limits and force settings according to the manual to ensure smooth operation.

PROGRAMMING YOUR GENIE H 8000 07 REMOTE AND KEYPAD

Once the physical installation is complete, you will need to program your remote controls and wireless keypad to communicate with the opener. The Genie H 8000 07 uses Intellicode technology, which simplifies pairing while maintaining high security.

Programming a Remote Control

1. Locate the "Learn Code" button on the power head. On the Genie H 8000 07, this button is typically round and may be colored red, green, or purple.
2. Press and release the "Learn Code" button. An LED indicator will light up, indicating that the opener is in programming mode for 30 seconds.
3. Within that 30-second window, press and hold the button on your remote control that you wish to use. Hold it until the opener's lights flash or you hear a clicking

sound, confirming synchronization.

4. Release the remote button. Test the remote by pressing it to open or close the garage door from a distance.

Programming the Wireless Keypad

1. Press the "Learn Code" button on the power head and release it. The LED indicator will activate.
2. Enter a 4-digit PIN of your choice on the wireless keypad, then press the "Up/Down" or "Enter" button (depending on your keypad model).
3. The opener's lights will flash to

confirm successful programming.

Test the keypad by entering your PIN and pressing the enter or arrow button.

4. If your keypad supports multiple PINs, repeat the process for additional users, such as family members or service personnel.

Erasing All Remote Codes

If you need to reset all paired remotes and keypads (for example, after losing a remote or moving into a new home), press and hold the "Learn Code" button on the power head for approximately 10 seconds until the LED turns off. This

erases all stored codes. You can then reprogram each remote and keypad individually.

TROUBLESHOOTING COMMON ISSUES WITH THE GENIE H 8000 07

Even the most reliable garage door openers may encounter occasional issues. Below are some of the most common problems experienced by Genie H 8000 07 owners, along with practical solutions.

The Door Does

Not Respond to Remote or Wall Console

- Check that the power head is plugged in and the circuit breaker has not tripped.
- Verify that the wall console is properly connected and the wiring is secure.
- Replace the batteries in your remote control and try again.
- If the opener still does not respond, press the "Learn Code" button and attempt to reprogram the remote.

The Garage Door Opens but Will Not Close Fully

- Inspect the Safe-T-Beam sensors for misalignment or obstruction. Clean the lenses with a soft cloth and ensure the indicator lights are steady.
- Check the travel limit settings. If the down limit is set too high, the door may not close completely. Adjust the limit switches according to the manual.
- Examine the door tracks and rollers for debris or damage that

could impede movement.

The Opener Makes Noise but the Door Does Not Move

- This usually indicates an issue with the chain drive or the trolley mechanism. Inspect the chain for proper tension and ensure it is not jammed.
- Check the engagement of the manual release handle. If it is accidentally pulled, the opener will

run but the door will remain stationary. Pull the release handle toward the door to re-engage it.

- If the problem persists, the motor or gear assembly may require professional service.

The Lights Do Not Turn On or Stay On Too Long

- Check the light bulbs and replace them if burned out. Use only bulbs with the recommended wattage

(100 watts maximum).

- Some Genie models allow you to adjust the light timer. Refer to your manual to set the desired duration (typically 1 to 5 minutes).
- If the lights remain on continuously, the wall console may be stuck in the "light on" position. Toggle the light button to reset it.

MAINTENANCE TIPS FOR LONGEVITY OF YOUR GENIE H 8000 07

Regular maintenance will extend the life of your garage door opener and ensure safe, quiet operation. Incorporate these simple tasks into your routine.

Monthly Visual Inspection

Take a few minutes each month to visually inspect the chain, cables, rollers, and tracks. Look for signs of wear, rust, or loose hardware. Tighten any bolts that appear loose and replace worn parts promptly.

Lubrication Schedule

Apply a silicone-based lubricant or garage door-specific grease to the chain, rollers, hinges, and tracks every six months. Avoid using WD-40 or

petroleum-based products, as they can attract dust and cause buildup. Proper lubrication reduces noise and friction, allowing the opener to work more efficiently.

Test Safety Features Monthly

Place a small object, such as a block of wood, in the path of the closing door. The door should reverse immediately upon contact with the object. Also, wave an object through the Safe-T-Beam sensors while the door is closing to confirm it reverses. If either test fails, adjust the sensors or consult the manual for troubleshooting.

Check Battery Backup (If Applicable)

If your Genie H 8000 07 is equipped with a battery backup system, test the

batteries every three months by unplugging the opener and operating the door using the wall console. Replace the backup batteries according to the manufacturer's schedule, typically every 1 to 2 years.

SAFETY CONSIDERATIONS FOR THE GENIE H 8000 07

Garage door openers