

---

# Nikon Coolpix P 510 Guide

---

*Nikon  
Coolpix P  
510 Guide*

*Downloaded from  
[www.whlarchitecture.com](http://www.whlarchitecture.com)  
by Gael & Keenan*

---

## INTRODUCTION: REDISCOVERING THE SUPERZOOM POWER OF THE NIKON COOLPIX P510

---

In an era where smartphone cameras dominate casual photography, a dedicated device like the **Nikon Coolpix P510** still holds a special place for enthusiasts who crave optical reach and creative control. Released as a bridge camera, the P510 was designed to bridge the gap between a point-

and-shoot and a full-fledged DSLR. Its claim to fame was, and still is, its incredible 42x optical zoom lens, which offers a 35mm equivalent range of 24mm to 1000mm. For anyone looking for a comprehensive **Nikon Coolpix P 510 guide**, you have come to the right place. Whether you are a beginner digging an old camera out of a drawer or a hobbyist looking to maximize your gear, understanding the nuances of this versatile camera can unlock a world of photographic possibilities.

The Nikon Coolpix P510 is more than just a zoom lens attached to a sensor. It packs a 16.1-megapixel backside-illuminated CMOS sensor, a built-in GPS for geotagging, and a variety of manual controls that allow you to grow as a photographer. In this guide, we will walk you through everything from the initial setup to advanced shooting techniques, ensuring you get the most out of your superzoom camera.

---

## **GETTING STARTED: SETTING UP YOUR NIKON COOLPIX P510**

---

Before you start capturing distant mountains or elusive wildlife, you need to ensure your camera is properly configured. The setup process is

straightforward, but a few key steps will ensure optimal performance from the start.

# Charging the Battery and Inserting Memory Card

The P510 uses a rechargeable EN-EL5 lithium-ion battery. Upon unboxing, you should fully charge the battery using the supplied charger. A full charge typically takes about two and a half hours. While the

camera has internal memory for testing, you will need a Secure Digital (SD) memory card for serious shooting. The P510 supports SD, SDHC, and SDXC cards. Insert the card with the label facing the back of the camera, pushing it in until it clicks. To format the card, go to the setup menu and select **Format memory card**. Formatting is recommended for a fresh start to prevent file system errors.

# Initial Date, Time, and Language

## Settings

When you power on the camera for the first time, it will prompt you to set the language, date, and time. This is particularly important for the **GPS geotagging feature**, as accurate time stamps are required to match location data. Ensure you set your home time zone correctly. If you travel, the P510 allows you to set a destination time zone, which is helpful for organizing photos by location later.

---

### UNDERSTANDING THE CORE FEATURES OF THE NIKON COOLPIX P510

---

To master this camera, you need to understand the technology inside it.

The P510 was a flagship superzoom in its day, and its features still hold up remarkably well for casual and enthusiast use.

## The 42x Optical Zoom:

From  
Wide to  
Telephoto

The most defining feature of the P510 is its NIKKOR lens with 42x optical zoom. At the wide-angle end (24mm), you can capture expansive landscapes and group shots. As you zoom in to the telephoto end (1000mm), you can

photograph distant subjects like birds, the moon, or performers on a stage. The camera features **Vibration Reduction (VR)**, which is essential at such extreme focal lengths. Even with VR, using a tripod or monopod at full zoom yields significantly sharper images.

16.1  
Megapixe  
l CMOS  
Sensor

The backside-illuminated CMOS sensor delivers good low-light performance compared to older CCD sensors. It allows for faster continuous shooting speeds and better image quality at

higher ISO settings. While it won't match a modern DSLR, it produces vibrant, detailed images suitable for printing up to large sizes.

## The Electronic Viewfinder (EVF) and Vari-Angle LCD

The P510 offers two ways to compose your shot. The electronic viewfinder is handy in bright sunlight when the LCD screen is hard to see. The 3-inch vari-angle LCD can be tilted

and swiveled, making it perfect for shooting over crowds or getting low-angle macro shots of flowers.

---

### MASTERING THE SHOOTING MODES FOR EVERY SCENARIO

---

One of the strengths of the **Nikon Coolpix P 510 guide** is understanding its shooting modes. The camera offers a range of automatic and manual settings to suit different skill levels.

## Auto Mode and Scene Modes

If you are just starting out, the green **Auto mode** is your best

friend. It analyzes the scene and selects the optimal settings. For more specific situations, the Scene mode (SCENE) offers presets like Portrait, Landscape, Sports, Night Portrait, and Moon. The Moon scene is particularly popular among P510 owners due to the camera's massive zoom, allowing you to capture clear details of the lunar surface.

## P, S, A, and M Modes: Taking Creative

# Control

- **Program Mode**

**(P):** The camera sets aperture and shutter speed, but you can adjust other settings like ISO and white balance.

- **Shutter Priority**

**(S):** You control the shutter speed; the camera adjusts aperture. Use this for freezing fast action (e.g., sports, birds in flight) or creating motion blur (e.g., waterfalls).

- **Aperture**

**Priority (A):** You control the aperture to manage depth of field. A small f-number (e.g., f/3.0) blurs the

background, while a large f-number (e.g., f/8.0) keeps everything in focus.

- **Manual Mode (M):** Full control over both shutter speed and aperture. This is ideal for consistent exposure in tricky lighting or for long exposures at night.

configuration of settings, such as a specific white balance, ISO, and focus mode. This is a time-saver if you frequently shoot in a particular style.

---

### **PRACTICAL TIPS FOR STUNNING PHOTOS WITH YOUR P510**

---

Knowing your camera's settings is one thing; applying them in the field is another. Here are actionable tips to elevate your photography with the Nikon Coolpix P510.

## Using the Custom Settings Bank

The P510 has a U (User) setting on the mode dial. You can save your favorite

## Stabilization is Key at Full

# Zoom

At 1000mm, even a slight hand tremor will result in a blurry image. While the lens VR is effective, it has limits. Always brace yourself: tuck your elbows in, lean against a solid object, or use a tripod. Consider using the **self-timer** or a remote release to avoid shaking the camera when pressing the shutter button.

flower icon) to capture intricate details of insects, flowers, or textures. At the wide-angle end, you can focus as close as 1 centimeter from the subject. Use Aperture Priority mode and a smaller aperture (higher f-number) to ensure the entire subject stays in focus.

# Leveraging the Macro Mode of the Moon

Don't underestimate the P510's close-up capability. Switch to **Macro mode** (the

# Get the Most Out of the Moon Mode

The P510's Moon scene mode is legendary among bridge cameras. It automatically sets a low ISO, a narrow aperture, and a fast



shutter speed. For best results, use a tripod, zoom to maximum telephoto, and use the self-timer. You can even slightly underexpose the image to retain crater details.

## Managing Noise at High ISO

While the P510 performs decently up to ISO 800, noise becomes noticeable at ISO 1600 and above. In low light, try to use a wider aperture or slower shutter speed before increasing ISO. If you must use high ISO, shooting in RAW format allows you to reduce noise more effectively in post-processing.

---

### USING THE BUILT-IN GPS AND GEOTAGGING

---

A standout feature of the P510 is its built-in GPS receiver. This allows you to automatically embed latitude and longitude coordinates into your photo's EXIF data. This is perfect for travel photographers who want to remember exactly where each shot was taken.

## Enabling GPS and Recording Logs

To activate GPS, press the GPS button on the top of the camera. It may take a few minutes to acquire a

satellite signal outdoors. You can also record a travel log, which tracks your route even when the camera is off. This log can be synced with photos later using Nikon software. Note that using GPS will drain the battery faster, so it is wise to carry a spare battery if you plan to use it extensively.

---

### **RECOMMENDED ACCESSORIES FOR YOUR NIKON COOLPIX P510**

---

To fully realize the potential of this camera, a few accessories are highly recommended.

- **Extra Battery (EN-EL5):** The P510 is power-hungry, especially with heavy zoom usage and GPS.

A spare battery is essential for a full day of shooting.

- **Sturdy Tripod:**

Given the 1000mm zoom, a tripod is not optional for sharp telephoto shots. Look for one that can support the camera's weight without wobbling.

- **Lens Adapter and Filters:** The P510 has a lens thread that supports a 52mm filter with an adapter ring. A polarizing filter can reduce glare and enhance skies, while a UV filter protects the front element.

- **Carrying Case:** A padded case protects your

investment and makes it easier to carry the camera along with spare batteries and memory cards.

## **TROUBLESHOOTING COMMON ISSUES**

Even well-maintained cameras can encounter hiccups. Here is how to handle common issues with the P510.

### **Lens Error**

If you see a **Lens error** message, it often means the lens is jammed or obstructed. Try turning the camera off and on again. If the error persists, check the lens barrel for dust or sand. Gently blowing air around the lens can sometimes dislodge

debris. Avoid forcing the lens manually.

### **GPS Not Acquiring Signal**

GPS requires a clear view of the sky. Move away from tall buildings or dense tree cover. Ensure the GPS feature is turned on. If the signal is weak, wait a few minutes for the camera to lock onto satellites.

### **Battery Draining Quickly**

If your battery life is shorter than expected, check if GPS is constantly on. Also, frequent use of the

flash and the LCD screen will drain power. Turning off image review after each shot can also save battery life.

---

## **CONCLUSION: IS THE NIKON COOLPIX P510 STILL WORTH USING?**

---

In a world of mirrorless cameras and advanced smartphones, the **Nikon Coolpix P510** remains a remarkably capable tool for anyone who values optical zoom range above all else. Its 42x zoom, combined with manual controls and GPS geotagging, offers a level of versatility that is hard to find at a comparable price point even today. While its sensor technology is older and its low-light performance is not class-leading, the

sheer reach of its lens allows you to capture images that would be impossible with other compact cameras.

Whether you are documenting your travels, photographing wildlife from a safe distance, or simply exploring the world of creative photography, the P510 is a trusted companion. By following the advice in this **Nikon Coolpix P 510 guide**, you can overcome its limitations, leverage its strengths, and consistently produce sharp, compelling photographs. It is a camera that rewards patience and practice, and for the dedicated user, it remains a superb gateway into the art of superzoom photography.

So, charge your battery, insert a fresh

memory card, and step looks very different  
outside. The world through a 1000mm  
lens,